
IDS701
Weighing Indicator

User manual



safety instruction

For safety operation pls. follow the safety instruction.



WARNING

set. Calibrate, inspect and fix the the weighing indicator is prohibited by
Non professional staff



WARNING

Pls. make sure the weighing display well earthing

ATTENTION



OBSERVE PRECAUTIONS
FOR HANDLING
ELECTROSTATIC
SENSITIVE DEVICES



WARNING

The indicator is electrostatic sensitive device, pls.
power off during electrical connections, internal
components touched by hand is prohibited, and please
take the anti-static measure

LIST

1. Summary -----	3
1.1 Main function-----	3
1.2 Optional function-----	3
1.3 Technical parameter-----	3
1.4 Outline and installation drawing-----	4
1.5 Battery using-----	4
2. Installation -----	5
2.1 Connection between indicator and load cell-----	5
2.2 Connection of interface-----	5
3. Basic operation -----	6
3.1 Display and key instruction-----	6
3.2 Power on-----	8
3.3 Zero function-----	8
3.4 Tare function-----	8
3.5 Accumulating function-----	9
3.6 Print function-----	10
3.7 Hold function-----	10
4. Calibration -----	11
4.1 Enter and exit setting-----	11
4.2 Calibration steps-----	12
4.3 Parameter setting-----	14
5. Output data format -----	18
6. Maintenance -----	21

1. Summary

IDS701 is specially designed for platform scale with friendly interface, simple operation, steady feature. The Basic function includes Weigh, Peak hold, Print. Communicate, Options are accumulate, Count and animal weighing.

1.1 Main function

- » basic weighing function: zero tare
- » peak hold
- » hold
- » low battery remind charge and stop charge controlled
- » PC communication
- » Automatically power off


1.2 Optional function

- » accumulating function
- » animal weighing
- » printing function(with time)

1.3 Technical parameter

- » Stimulating voltage: +5VDC
- » A/D converting speed: 10 times/sec
- » load capacity: it can connect 4 pcs 350Ω load cell at most
- » Resolution: 3000e
- » Interval: 1/2/5/10/20/50
- » Display: 6-digits LED, word height: 20.3mm
- » key: ON/OFF TOTAL TARE ZERO SET
- » Interface: RS232C Baud rate optional 1200/2400/4800/9600
- » Ambient temperature: -10~40℃
- » optional power: 6V/4Ah rechargeable battery; 9VDC adapter

1.4 Outline and installation picture




1.5 Battery

1. when you use the internal battery first time, you should charge the battery 10-12 hours, to prevent low voltage resulted from self leakage of battery.
2. when the red battery light is on and flashes, it means low battery You should charge battery in time.
3. Charge time: 10-12 hours And it works 45 hours
4. When the battery light turns green, it means fully charged
5. If you don't use the battery long time, take out the battery to protect t the indicator from battery leakage
6. In order to keep the battery in best using condition, it is suggest that you fully discharge the battery every month, the method is that using the indicator till it is automatically power off.

2. Installation and Calibration

2.1 connection indicator with loadcell


IDS701 can connect four pcs 350Ω load cell at most, both four and six wire load cell are ok. To make it simple, we use quick disconnect Or standard plug. As belows



Quick disconnect connection

2.2 Connection of interface


RS232 communication interface use 3 cores quick connector



RS232 communication interface connection



3. Basic operation

3.1 Key and display








IDS701 Weighing indicator display instruction

LED display	instruction
	Weighing data display
Total	accumulating

Hold	Hold weighing data
Tare	Display tare weight
Net	Display net weight
Gross	Display gross weight
	Display data keep still
	zero, indicating zero weight
Battery	Using battery
Hi	Over setting weight
OK	Within setting weight
Lo	Below setting weight
.	Decimal point

Key's function


Key symbol	Key name	Key function
	SET	Work together with zero, tare, on/off to perform all operations.
	ZERO	1. Clear weight within zero range 2. Work together with SET to perform Hold and animal-weighing operation.

	TARE	1.At Gross mode, tare the loaded weight 2.At Net mode, display gross weight after deduct tare
	TOTAL	Work together with SET perform accumulating operation
	ON/OFF	1.Press it for 2 seconds to power on or power off 2.Work together with "SET" to enter calibration and function setting.


3.2 Power on


Power on and indicator perform self-checking and go to weighing mode.

3.3 Zero setting

Within zero range, press , indicator weighing is cleared. When Indicator is not stable, zero is unworkable.


3.4 TARE


Press , take the loaded weight as tare, display net weight, Net weight is zero. "tare" "net" status light is on.

At the Tare mode, Press , clear the tare, display gross weight.

3.5 TOTAL


Accumulation operation

At Zero mode, load weight till stable, Press  go to accumulating Mode, "total" light on, display "n001", and then display loaded weight;

unload weight, back to zero, load weight again till stable. Press , display "n002"

Then display the loaded weight. Repeat it maximum 999 times.

Check the total weight operation:



Press  and hold it then press 



At the same time, display "n**", (accumulating times) then display total weight.

There are 8 data totally. It shows the first 4 digital. then the last 4 digital

For example, the first 4 digital is "0012", the last 4 digital is "34,56"

It means the actual weight is "1234.56"

At TOTAL (accumulate) mode, Press  display "clr n", it means don't clear the total Weight, Press  exit it; if clear total weight,

Press  "clr n" change to "clr y" it means clear total weight display. Press  to clear the the total weight and exit accumulating mode.

3.6 Print function

When the data is stable, connection with printer, it will be printed after press "set" 1 second.



Note: print the gross weight when at tare mode, if the net weight is zero. Can not print.

3.7 Hold function

There are two different hold function. Peak hold function and data hold function. And the setting is different accordingly.


C11=1 Peak hold C11=2 Data hold C11=0 no hold function


Peak-hold: display the maximum weight. At weighing mode, Press

 still, then press , display the "lock" weight. "hold"

Light is on. At that time, you load or unload stuff, the weight keep still

Data hold: display the "lock" weight. Press  still, then press

, display the "lock" weight. "hold" Light is on. At that time, you load

or unload weight, the weight keep still. At "hold" mode, Press 

hold it and then press  to exit hold mode. "hold" light is off.

3.8 10 times high resolution

At weighing mode. Press  hold it and then press 



There is one more digital display. It is 10 times high resolution display.

4. Calibration and parameter setting

4.1 Enter setting

There have two methods to enter the setting menu:


1. when the "span" is not pressed down,

Press  still and then press  enter C08-C39 setting.

2. Take out the sealing screw on the back of indicator, then press

down the "span" Press  still and then press  enter C01-C39 setting.


The key functions in setting:

 Enter

 Up

 Down

 Left

 Power switch. exit setting

4.2. Step of calibration operation:

According to the second method which can enter setting menu, C01-C39

step	Method of operation	display	Remark
1		[C01]	After you enter to calibration mode, it display [C01]
2	press ←	[C1 1]	Weight unit option: 1=kg
3	press ← press ← press ↑ or ↓	[C02] [C02 0] [C02 2]	Set decimal digits option: 0/1/2/3/4 Select decimal digit example: two decimal point: [C02 2]
4	press ← press ← press ↑ or ↓	[C03] [C03 1] [C03 5]	Set graduation option: 1/2/5/10/20/50 Select required graduation example: graduation 5: [C03 5]
5	press ← press ← press ↑ or ↓/←	[C04] [0100.00] [0100.00]	Max capacity example: max weighing 100kg: [0100.00]
6	press ← press ← press ↑ press ←	[C05] [C05 0] [C05 1] [CAL 9] [0000.00]	Zero calibration option : 0=non-calibration zero 1=need calibration zero calibration zero please choose 1 and ensure scale is empty and "stable" light is on

			Ensure zero calibration, countdown. Till show[0.00](example for two decimal point).
7	<p>press ←</p> <p>press ←</p> <p>press ↑ or ↓</p> <p>press ←</p> <p>press ↑ or ↓</p> <p>press ←</p>	<p>[C06]</p> <p>[C06 0]</p> <p>[C06 1]</p> <p>[SPAN]</p> <p>[0100.00]</p> <p>[0080.00]</p> <p>[CAL 9]</p> <p>.....</p> <p>[0080.00]</p> <p>[CALEnd]</p>	<p>Loading calibration option:</p> <p>0=Non-load calibration 1= load calibration</p> <p>Basic on max capacity setting, add suitable weight on scale, close to the max capacity, heavier than 10% max at least.</p> <p>For example: the weight is 80kg As bellows: enter loading calibration, count down over, indicator shows loaded weight , loading calibration finish.</p> <p>If you want to set application Function parameter. Press "PRINT" if you want to exit press "TOTAL"</p>
8	<p>press ←</p> <p>press ←</p> <p>press ↑ or ↓</p>	<p>[C07]</p> <p>[07 0]</p> <p>[07 1]</p>	<p>Default parameters setting option:0=non-restore default parameters 1=restore default parameters</p> <p>Note: after the above parameters setting finish, please</p>

			do not set default parameters often, avoid the original setting parameters lost.
--	--	--	----------------------------------------------------------------------------------

4.3 Application function parameters setting chart

Function	Setting Item	parameters setting and instruction
warning tone	C08 warning tone	Options: 0 = close warning tone 1 = open warning tone
Automatic power off	C09 Automatic power off	option: 0=close auto power off 10= keep still within 10 min. power off automatically 30= keep still within 30 min. power off automatically 60= keep still within 60 min. power off automatically
Power saving setting	C10 Power saving setting	option: 0= close power saving setting 3= keep still within 3 min. stop display 5= keep still within 5 min. stop display
Hold function	C11 Hold mode	option: 0=close hold function 1=Peak hold /2=Data Hold instruction: Peak : it shows the max. data, mainly application for materials testing, such as tension and pulling force. Hold: it shows current weight value. Mainly application for animal weighing.

	C12	
Upper/lower limit alarm	C13 Upper limit alarm value	You can set it within the max. capacity limit
	C14 Lower limit alarm value	
Inner Code display	C15 Check inner code	At setting function mode, after directly enter C15, indicator will show inner code
Date and time	C16 Date	Enter C16, you can direct to set the current date, from left to right: year/month/day
	C17 Time	Enter C16, you can direct to set the current date, from left to right: year/month/day
Communication setting	C18 Serial interface data method output	option: 0= Close serial interface data output 1= Continuous sending, connect big display 2=print method, connect printer. 3= Command request method , connect computer. 4=PC continues to sending format, connect computer.
	C19 Baud rate	option: 0=1200/1=2400/2=4800/3=9600
Zero range	C20	option: 0= close manually zero setting

	Manually zero range	1=±1% max capacity 2=±2% max capacity 4=±4% max capacity
	C21 Initial zero range	option: 0= no initial zero 1=±1% max capacity


		5=±5% max capacity 10=±10% max capacity 20=±20% max capacity
Automatic zero tracking	C22 Automatic zero tracking range	option: 0.0= close automatic zero tracking 0.5=±0.5d 1.0=±1.0d 2.0=±2.0d 3.0=±3.0d 4.0=±4.0d 5.0=±5.0d remark: 1.d is the set graduation 2. Automatic zero tracking range can not exceed manual zero setting range
	C23 Automatic zero tracking time	option: 0= close automatic zero tracking time 1=1 second 2=2 seconds 3=3 seconds
Overload range	C24 Overload range	option: 00= close overload range 01d~99d remark: d is the setting graduation

		(division)
Negative display	C25 Negative display	Option: 0=-9d 10=10% max. capacity 20=20% max. capacity
Standstill setting	C26 Standstill time	option: 0= quick 1= medium 2= slow
	C27 Standstill range	option: 1=1d 2=2d 5=5d 10=10d Note: d=division
Digital filter	C28 Dynamic filter Instruction : Dynamic filter is collecting the data filter before loaded weight stable. When loaded weight easily shaking (for example animal) , you can set this filter to make weight display more stable	option: 0= close dynamic filter 1=1 digital filter strength 2=2 digital filter strength 3=3 digital filter strength 4=4 digital filter strength 5=5 digital filter strength 6=6 digital filter strength Note: Pls setting dynamic filter strength carefully, the No. is bigger, more stable. if the loaded weight shake not too much. The setting is less than 3
	C29 Noise filter	option: 0=close noise filter 1=1 digital filter strength

		2=2 digital filter strength 3=3 digital filter strength
	C30 Print time and date	C30=0 yy.mm.dd C30=1 mm.dd.yy C30=2 dd.mm.yy C30=3 yy.mm.dd

5. Output data format

5.1 Computer continuous sending format



- S1: weight status, ST= standstill, US= not standstill, OL= overload
- S2: weight mode, GS=gross mode, NT=net mode
- S3: weight of positive and negative, "+" or "-"
- S4: measurement unit, "kg" or "lb"
- Data: weight value, including decimal point
- CR: carriage return
- LF: line feed

5.2 Big display continuous sending format

Output continuous format																	
S	S	S	S	X	X	X	X	X	X	X	X	X	X	X	X	C	C
T	W	W	W												R	K	
X	A	B	C													S	
1	2			3						4				5	6		

State A			
Bits0,1,2			
0	1	2	Decimal point position
1	0	0	XXXXXX0
0	1	0	XXXXXXX
1	1	0	XXXXX. X
0	0	1	XXXX. XX
1	0	1	XXX. XXX
Bits3,4			Division
0	1		X1
1	0		X2

State B	
BitsS	function
Bits0	gross=0, net=1
Bits1	symbol: positive =0, negative =1
Bits2	overload (or lower zero) =1
Bits3	dynamic=1
Bits4	unit: lb=0, kg=1
Bits5	Constant 1
Bits6	Constant 0